



- 0) You will need to check the Pre-Vault area C-Blocks in AP0, verify that the chains are in place and locked with 2 padlocks. Bring AP0 keys.
- 1) Enter the Pre-Target & Pre-Vault Enclosures from the upstream end of AP0.

The following steps are required to secure both Pre-Target and Pre-Vault

- 2) "A" & "B" proceed to Pre-Target Interlock Box #1 at the top of the stairwell and reset it.
- 3) "A" & "B" sweep the enclosure to Interlock Box #2,
- 4) "A" resets Interlock Box #2, "A" and "B" control access into Pre-Vault.

If only Pre-Vault secure is required, you can start here.

- 5) "A" reset Interlock Box #1 of Pre-Vault.
- 6) "A" holds while "B" checks the hallway.
- 7) "A" & "B" sweep the enclosure to the stairwell. Check the area between the stairwell and the target wall
- 8) "A" & "B" exit the stairwell to reset Interlock Box #2 and control access out.

Reviewed AD/RSO	Date
<i>Michael A. Gerard</i>	4-1-09
Approved AD/OPS Dept. Head	Date
<i>[Signature]</i>	4-2-09